

## 曲轴飞轮部分 Crankshaft Flywheel

序号 No.	零部件图号 Part No.	名称	Part Name	每台数量 Qty										规格标准 Standard Specification		
				HOWO					A7							
				D12.34-30	D12.38-30	D12.42-30	D12.46-30		D12.34-30	D12.38-30	D12.42-30	D12.46-30				
1	AZ1246020013	曲轴	Crankshaft	1	1	1	1			1	1	1	1			
2	VG1246020012	曲轴前齿轮	Front crankshaft gear	1	1	1	1			1	1	1	1			
3	VG1246020011	曲轴后齿轮	Rear crankshaft gear	1	1	1	1			1	1	1	1			
4	Q5210816	圆柱销	Dowel pin	2	2	2	2			2	2	2	2			
5	AZ1246020005A	飞轮	Flywheel	1	1	1	1			1	1	1	1			
6	Q43062	孔用弹性挡圈	Circlip	1	1	1	1			1	1	1	1			
7	190003311416	球轴承	Ball bearing	1	1	1	1			1	1	1	1			DIN625 630 52RS
8	VG2600020208	飞轮齿圈	Ring gear	1	1	1	1			1	1	1	1			
9	Q1201090F3	双头螺柱	Stud	2	2	2	2			2	2	2	2			
10	Q340B10	六角螺母	Hexagon nut	2	2	2	2			2	2	2	2			
11	Q150B1085	六角头螺栓	Hex head bolt	10	10	10	10			10	10	10	10			
12	Q41810	波形弹性垫圈	Spring washer	12	12	12	12			12	12	12	12			
13	VG1246020010	飞轮螺栓	Flywheel bolt	9	9	9	9			9	9	9	9			
14	VG1246020001	曲轴皮带轮	Crankshaft belt pulley	1	1	1	1			1	1	1	1			
15	VG1246020002	硅油减震器	Vibration damper	1	1	1	1			1	1	1	1			
16	VG1246020003	垫环	Washer	1	1	1	1			1	1	1	1			
17	Q150B1030	六角头螺栓	Hex head bolt	6	6	6	6			6	6	6	6			
18	VG1246020004	六角头螺栓	Hex head bolt	6	6	6	6			6	6	6	6			

# 曲轴飞轮部分 Crankshaft Flywheel

